




GA Item # 804122

HLM 20-300 NG APZ High/Low Gas Controller

Controls groups of heaters totaling (up to) 310,000 Btu's (Natural Gas)



WESTERN HEMISPHERE
Gasolec America, Inc.
Phone: 1-918-455-4588
Fax: 1-918-455-4396

5818 S. 129th E. Ave.
Tulsa, OK 74134



Your energy savings experts



www.gasolecusa.com

EASTERN HEMISPHERE
Gasolec B.V.
Phone: (+31)172-636636
Fax: (+31)172-636630

P.O. Box 183
2410 AD Bodegraven
The Netherlands

1. Source of gas

- A. LP tank
- B. LP Cylinders Battery
- C. Metered Natural Gas




2. "First Stage Regulator"

Typically located at the tank, tank battery, or NG meter.



Gasolec PR 300M
GA Item # 803205

1st Stage Regulator
(at tank or battery)




3. "Second Stage Regulator" located at the building



Gasolec PR 300M
GA Item # 803205

2nd Stage Regulator
(at Building)



4. Select the thermostat



Your central controller

or



Gasolec ETC Digital Thermostat
GA Item # 802105

or



Gasolec MT-16 Thermostat
GA Item # 802100

